

FREE SAMPLE

The opening pages of

1968 Chevrolet Corvette Restoration Guide

Read these pages exactly as they appear in the full guide.
Nothing here is rewritten or summarised — it is the product itself,
so you can judge the depth before you spend a dollar.

Get the full guide: <https://restoreessentials.com/product/RE-GD-CHEVROLET-CORVETTE-1968>

RestorationEssentials — instant PDF download after checkout.



RESTORATIONESSENTIALS

1968 Chevrolet Corvette

Factory-Correct Restoration Guide

Key facts at a glance

Engines	Two 327s (300, 350 hp) and four 427s (390-430 hp) Landmark First year of the C3; first T-top Corvette; no Sting Ray badging VIN format 13-character:...
Production	28,566 (9,936 coupes / 18,630 convertibles)

restorationessentials.polsia.app

Single-year coverage. Factory-correct specifications. No guesswork.

SAMPLE EXCERPT — full guide available at the link on the cover sheet



How to Use This Guide

This guide covers one model year -- the 1968 Chevrolet Corvette -- and nothing else. Every specification, code, and production figure applies to cars built for the 1968 model year; where a part or practice carried over from 1967 or continued into 1969, the text says so.

Work in this order: (1) Decode the VIN (Section 4) and the trim tag (Section 5) before you believe anything about the car. (2) Verify the engine, transmission, and axle against Sections 6, 7, and 10 -- the VIN, the pad stamp, the casting numbers, and the dates must all agree. (3) Check the car's colors and options against Sections 8 and 9. (4) Inspect the frame and birdcage (Section 12) before you spend money -- structural repair dwarfs every other cost. (5) Follow the restoration sequence (Section 13) in order; it is written to keep you from doing work twice.

Where the sources disagreed, Section 20 tells you -- this guide reports conflicts instead of hiding them.

1. Chevrolet: The Division That Built America's Sports Car

Chevrolet was founded in 1911 by Swiss-born racing driver Louis Chevrolet and ousted General Motors founder William C. Durant, who needed a new car company after losing control of GM. The bowtie badge appeared in 1913 — Durant claimed he saw the shape on a French hotel wallpaper — and by 1918 Chevrolet was profitable enough for Durant to use it to buy his way back into General Motors. Chevrolet has been GM's volume division ever since: the cars that paid for everything else. The division's engineering reputation was built on durable, affordable power. The 1929 'Stovebolt' overhead-valve six gave Chevrolet buyers modern valve gear at Ford Model A prices, and the six-cylinder lineage carried the division through the Depression and World War II. After the war, Chevrolet owned the low-price field with the Bel Air and the Tri-Five Chevrolets of 1955-1957 — cars that still define the American automobile in the popular imagination.

The defining moment came in 1955, when chief engineer Ed Cole's small-block V8 debuted: 265 cubic inches, lightweight, compact, and endlessly developable. The small-block grew to 283, 327, 350, and 400 cubic inches and powered everything from family wagons to the Corvette; it remains the most-produced V8 architecture in history. Chevrolet followed with the big-block 'porcupine' heads on the 1961 409, the 348/409 W-series, and the 1965 Mark IV big-block — the 396 that debuted in the 1965 Corvette, then the 427 and 454 that powered the muscle-car era.

By the 1960s Chevrolet was, by far, America's best-selling car brand, and its performance image was engineered as deliberately as its engines. The 1963 AMA racing ban pushed factory competition underground, but engineers like Zora Arkus-Duntov kept building faster Chevrolets through the back door of Regular Production Options — the COPO system, the L88, the ZL1, the ZR-1. The Corvette was Chevrolet's halo: every innovation that mattered, from fuel injection to four-wheel disc brakes, reached production in a Corvette first.

1968 Chevrolet Corvette

All Corvettes of the 1964-1973 era were assembled in St. Louis, Missouri, where fiberglass body production and final assembly shared one roof. The men and women of the St. Louis plant built every car this guide series covers — the peak Sting Rays and the early Stingrays alike — before Corvette production moved to Bowling Green, Kentucky, in mid-1981.

The W-series big-block — the 348 of 1958 and the 409 of 1961 — gave Chevrolet its NASCAR and drag-racing weapons, and the 409's 'porcupine' canted-valve heads pointed directly at the Mark IV. When the 396 debuted in the 1965 Corvette, it was the first of the new big-block family: stronger bottom end, better breathing, and a growth path to 427 and 454 cubic inches. Every big-block in this



es descends from that 1965 Mark IV.

Chevrolet's performance image was no accident. Product planners understood that a 16-year-old who dreamed about a 425-hp Corvette in 1965 became a Bel Air buyer in 1970 and a Caprice buyer in 1980 — the halo sold the mainstream. That is why the Corvette got the good hardware first and why Chevrolet protected the Corvette's primacy: no other Chevrolet could outrun the flagship, a rule enforced by everything from carburetor sizing to the famous internal ban on the Camaro beating the Corvette.

For the restorer, Chevrolet's scale is the good news. The division built millions of small-blocks and hundreds of thousands of big-blocks, the parts interchange across the Chevrolet line is the deepest in the hobby, and the factory documentation — assembly manuals, parts catalogs, dealer ordering guides — is the best-preserved of any American make. The challenge is not finding parts; it is finding the right parts, with the right numbers and the right dates, for the exact car in your garage. That is what this guide is for.

2. Corvette Model History

The first-generation Corvette (1953-1962) began as Harley Earl's 1953 Motorama dream car — 300 hand-built fiberglass roadsters with the Blue Flame six. The 1955 small-block V8 saved the car from cancellation, the 1957 fuel-injected 283 delivered one horsepower per cubic inch, and the 1962 327/360 closed the solid-axle era. The C1 established the Corvette's conventions: fiberglass bodywork, St. Louis assembly, the small-block V8, and the Regular Production Option system that put race-bred hardware on street cars.

The C3's predecessor — the 1963-1967 Sting Ray — established the formula the early Shark inherited: fiberglass body over a steel ladder frame, independent rear suspension, four-wheel disc brakes from 1965, and big-block power from the 1965-only 396 through the 1966-1967 427s. The C2's VIN carries no engine code, so C2 originality is proven entirely from stamps, castings, dates, and documentation — the same discipline the early C3 rewards, now aided by the pad's partial VIN derivative (1968-up) and the VIN engine code (1972-up).

The third-generation Corvette — the 1968-1982 'Shark,' drawn from the Mako Shark II show car — carried the C2's mechanical package forward in a dramatic new body. The 1968 coupe traded the 1968 Chevrolet Corvette

fastback for removable T-top roof panels, the fenders swelled into the Coke-bottle profile, and vacuum-operated pop-up headlamps replaced the C2's rotating units. The 1968 is the only C3 without Sting Ray/Stingray badging; the name returned in 1969 as one word.

The early C3 was the peak of the big-block era and the bridge across the muscle car's fall. The 427 continued through 1969 (with the 1969-only ZL1 all-aluminum 427 — two built), the 454 replaced it in 1970, and the LT-1 solid-lifter small-block and ZR-1 special-performance package debuted the same year. Compression ratios fell for 1971's unleaded fuel, the LS6 454/425 (188 built) marked the ultimate C3 big-block, 1972 switched to SAE net ratings and added the VIN engine code, and 1973 brought the urethane front bumper with chrome at the rear — the last chrome-rear-bumper Corvette. All early C3s were built in St. Louis on the 98-inch wheelbase.

For the restorer, the early C3's story is told in its one-year details: 1968's interior and vacuum systems, 1969's one-word Stingray badges, 1970's eggcrate grille and flares, 1971's fiber optics, 1972's VIN engine code, 1973's urethane nose. From 1968 on, the engine pad carries a partial VIN derivative — the single most powerful authentication tool in the Corvette hobby — and from 1972 the VIN itself names the engine.