

FREE SAMPLE

The opening pages of

1972 Chevrolet Suburban Restoration Guide

Read these pages exactly as they appear in the full guide.
Nothing here is rewritten or summarised — it is the product itself,
so you can judge the depth before you spend a dollar.

Get the full guide: <https://restoreessentials.com/product/RE-GD-CHEVROLET-SUBURBAN-1972>

RestorationEssentials — instant PDF download after checkout.



RESTORATIONESSENTIALS

Factory-Correct Restoration Reference

1972 Chevrolet Suburban Restoration Guide

Model Years 1972

Model	Chevrolet/GMC Suburban C10/C20/K10/K20
Platform	Body-on-frame; 127-in wheelbase; three-door
Engines	250/292 I6; 307/350 V8; 402 big block ('400')
Brakes	Front discs standard
Notable	Final Action Line year; Cheyenne Super

Every specification in this guide was checked against factory literature, marque references, period road tests, and documented survivor vehicles. Where sources disagree or the record is silent, this guide says so rather than guessing.

Published by RestorationEssentials

How This Guide Works

This is a **single-year restoration** guide for the 1972 Chevrolet/GMC Suburban — one year of the three-door Action Line generation (1967–1972), covered on its own because engines, trim, brakes, and details changed every year, and a factory-correct restoration matches the year on the VIN and the SPID, not the generation average. Specifications were checked against the range guide's factory-referenced base material, marque references, and period data. Where sources disagree, this guide prints the disagreement instead of guessing.



Scope. Covers 1972 C10/C20 (2WD) and K10/K20 (4WD) Suburbans, Chevrolet and GMC, with liftgate (model code 16) or panel doors (code 06). The separate panel truck and the K5 Blazer/Jimmy have their own guides.

Where 1972 sits in the run

- Coming in: 1971 brought discs, Cheyenne, the egg-crate grille, and 5-lug 2WD wheels.
- Leaving: 1973 replaces the generation: four doors arrive, the three-door era ends, and the coil-spring 2WD rear goes with it.

Year-Change Register — 1972

What makes a 1972 a 1972. Fit anything on this list from another year and the truck stops being factory-correct for its year.

- Final year of the Action Line Suburban — mechanically near-identical to 1971; the changes are in the details.
- Rear-view mirror is now glued to the windshield instead of bolted to the top of the cab.
- Flat metal/vinyl door panels are gone: all trims get molded plastic panels with integral armrests, woodgrain inserts on Cheyenne/Sierra; door and window cranks are slightly longer to suit.
- Vent windows are secured with a single screw on the inside of the door — a 1972 tell against 1971.
- Cheyenne Super tops the trim range; smaller rear A/C housing (range guide).
- Last coil-spring rear 2WD year — the 1973 redesign changes the formula.

Identity: VIN, SPID, and Documentation

- VIN pattern: the first characters decode as division / drive (C = 2WD, K = 4WD), engine (E = V8), series (1 = 1/2-ton, 2 = 3/4-ton), 09 = Suburban body, then 06 = panel doors or 16 = liftgate — e.g. CE10906 is a V8 C10 Suburban with panel doors; KE20916 a K20 4WD with liftgate.
- Assembly plants: F = Flint, J = Janesville, Z = Fremont, B = Baltimore, V = Pontiac, 1 = Oshawa. The plant letter is in the VIN; the frame stamping should match it.
- The SPID (Service Parts Identification) decal in the glovebox is the build sheet: every RPO the truck was born with. Photograph it before it deteriorates further — it is the single most important document on the truck.
- VINs can be transplanted from Blazers, panels, and other trucks sharing the format — verify the first characters against the body in front of you before paying for a story.

Engines — the 1972 Menu

Engine	Type	Notes
250 I6	Inline six	Standard engine
292 I6	Inline six	The big-six option
307 V8	Small block	Final year
350 V8	Small block	Final year of the run
402 V8	Big block	Badged '400'; largest factory engine of the run



The menu closes as it stood in 1971. The 402 remains the largest factory engine ever fitted to this generation — verify by casting number, as always, and expect the documented big-block 4x4s to sit at the top of the market.

Casting numbers rule. Badges lie and swaps are common: verify displacement by casting number and date code, and the engine against the VIN's engine code and the SPID, before valuing any truck.

Chassis, Suspension, and Brakes

Front discs carry over unchanged — the 1971 system, restored as a system. 1972's differences are in the cab details (mirror, door panels, cranks, vent screws), which is exactly where a careless restoration mixes years.

- 2WD: independent front suspension with coil springs; trailing-arm rear with coil springs (leaf rear optional; GMC standard/optional arrangement reversed). Trailing-arm bushings are the forgotten wear item — replace them.
- 4WD: leaf springs at both ends, Dana 44 front axle, NP205 gear-drive transfer case, manual locking hubs. Reseal the NP205 at minimum; service hubs, bearings, and U-joints.
- Steering: recirculating-ball box — rebuild it; 50 years of play is 50 years of wander. Tie rods and drag link with it.

Body, Rust, and Sheet Metal

- Rockers and floor pans — front footwells first; the 127-inch body means long rockers and long floors, and more exposure.
- Lower edges of all three doors; the third (curb-side rear) door's lower edge and frame are Suburban-specific rot points.
- Rear wheel arches and rear wheelhouses — probe from the cargo side; the cargo floor rots under mats and liners, which trap moisture and hide the truth.
- Tailgate / panel-door lower edges and frames; the rear of the truck collects water.
- Windshield frame lower corners at the gasket, and drip rails.
- Frame: tap the rails (ring good, thud bad), probe boxed sections and body-mount outriggers; mid-rails collect mud. A frame rotted mid-rail is a parts truck.
- Reproduction support is deep (LMC Truck, Classic Industries, Brothers) for floors, rockers, and doors — but order Suburban-specific panels; pickup panels do not stretch.

The Three-Door Body and the Rear Doors

Every 1967–1972 Suburban is a three-door: one driver's door, two curb-side doors, the rear door opening away from traffic. The third door's hinges, latches, and seals are Suburban-specific — rebuild sagging hinges rather than shimming the striker, clean seal channels to bare metal, and water-test before the interior goes in. At the rear, the SPID and model code say which the truck was born with: liftgate (16) or panel doors (06). Liftgate hinges, struts, and glass seals wear; panel-door hinges seize and both styles rot at the lower edge.