

FREE SAMPLE

The opening pages of

1967 Ford Fairlane Restoration Guide

Read these pages exactly as they appear in the full guide.
Nothing here is rewritten or summarised — it is the product itself,
so you can judge the depth before you spend a dollar.

The full guide: <https://restoreessentials.com/product/RE-GD-FORD-FAIRLANE-1967>

RestorationEssentials — instant PDF download after checkout.



RESTORATIONESSENTIALS

1967 Ford Fairlane

Factory-Correct Restoration Guide

Key facts at a glance

restorationessentials.polsia.app

Single-year coverage. Factory-correct specifications. No guesswork.

SAMPLE EXCERPT — full guide available at the link on the cover sheet



About This Guide

This is the RestorationEssentials factory-correct restoration guide for the 1967 Ford Fairlane — one model, one year, nothing else. Every specification in this guide was checked against marque references, factory literature excerpts, and enthusiast documentation before it was written.

Our operating ethic is simple: we don't lie and we don't steal, we offer value. That means three things for this guide. First, no invented specifications — every number has a source. Second, where reputable sources disagree, the disagreement is disclosed in the text and in the Sources, Conflicts & Omissions section rather than papered over. Third, where a detail could not be verified, it is omitted and the omission is recorded — an honest gap beats a confident fabrication.

How to use this guide: start with the VIN and fender-tag (or door data plate) decoding sections to establish exactly what your car was when it left the factory. Use the engine, transmission, axle, paint, and casting sections to verify that what is on the car today matches what should be there. Use the rust and restoration-sequence sections to plan the work. And keep this guide in the shop — it is a working document, not a coffee-table book.

A final note: these cars are sixty years old. Parts have been swapped, tags have been lost, and memories have faded. Trust

the metal — casting numbers, date codes, and stampings — over stories. When in doubt, photograph everything and verify

against the factory service manual for your year.

1. Manufacturer History: Ford

Ford Motor Company was founded in 1903 by Henry Ford, and within a decade the Model T and the moving assembly line had put the world on wheels — and made Ford the defining industrial company of the twentieth century. Through the Depression and the war years Ford remained one of the Big Three, and by the 1960s it was a company with the engineering depth and the racing ambition to take on the world. The 1960s were Ford's Total Performance decade. The 1964½ Mustang created the pony-car segment overnight. The 427-powered Galaxies and Fairlans dominated stock-car and drag racing. The GT40 won Le Mans four straight years (1966-1969). And the intermediate Fairlane/Torino line became Ford's muscle-car home — from the 1966 GTA to the aero-warrior Talladega and the 429-powered Cobra Jets. Ford's engineering culture shaped every car in this wave: the Windsor small-block V8 family, the FE big-block family, the 385-series (429/460) big-blocks, the Toploader four-speed, the C4/C6 automatics, and the 9-inch rear axle — arguably the strongest production rear axle ever built. For the restorer, the Ford corporate parts bin is deep, and Kevin Marti's licensed access to Ford's production database (the Marti Report) makes documentation unusually solid.

The 1970s brought emissions controls and the end of the high-compression era, and Ford pivoted to the Mustang II, compacts, and trucks. But the 1963-1973 performance cars — Falcon Sprint, Mustang, Fairlane/Torino, and the Shelby and Boss specials — remain cornerstone collector cars with one of the deepest reproduction ecosystems in the hobby.

1967 Ford Fairlane

2. Model History: Ford Fairlane

Ford created the mid-size Fairlane for 1962 — a clean-sheet intermediate that slotted between the compact Falcon and the full-size Galaxie, and became the test bed for the small-block V8: the 221, 260, and 289 were all designed for the Fairlane first, built only at Cleveland from 1962-1965. The 1963 Sports Coupe gave the line its style; the 1964 Thunderbolt (100 factory drag cars with the 427) gave it legend



The 1966 redesign made the Fairlane genuinely beautiful — and genuinely fast. The GT and GTA (GT with automatic) packed the 390 (335 hp), with the 427 available for the serious: 57 R-code cars in 1966, 229 in 1967. These are the peak collectible Fairlanes alongside the Thunderbolt and the K-code Sports Coupes (about 277 K-code 1963s).

For 1968 Ford split the intermediate line: Torino became the upscale series name and Fairlane continued as the base series — the cars share bodies, drivetrains, and VIN logic. The 1968-1970 Fairlanes are the affordable way into the Torino-generation cars, with engines from the 200 six to the 428 Cobra Jet (1968-69) and the 429 (1970).

1970 was the last year for the Fairlane name — from 1971 the entire intermediate line was Torino. The Fairlane's legacy is the small-block V8 itself: the Windsor family that powered everything from work trucks to Shelby Cobras started life in a 1962 Fairlane engine bay.

For the restorer, the Fairlane rewards Ford-system knowledge: the VIN's fifth character is the engine code, the door data plate carries body/paint/trim/date/axle/trans codes, and Kevin Marti's licensed Ford production database (the Marti Report, 1967-up) settles disputes the metal can't. Reproduction support is deep for 1966-67 GTs and Thunderbolt tribute parts; early (1962-65) trim is the sourcing challenge.

3. What Makes the 1967 Unique

The 1967 Fairlane refined the 1966 redesign — new grille, revised trim and interior — and the GT/GTA continued with the 390 detuned to 320 hp (S-code). GT production fell to 18,670 hardtops and 2,117 convertibles (reported): the 1967 GT convertible is the rarer car.

The 427 continued: 229 R-code cars reported for 1967, up from 57 in 1966 — still vanishingly rare, still documentation-or-nothing. The late-1967 Cleveland 289-block substitution (C8OE-6015-A 302 casting with 289 innards, per Auto History Preservation Society) is the running change that trips up drivetrain judging.

Engine range for 1967: 200 six (T), 289 2V (C, 200 hp), 289 4V (A, 225 hp), 289 HiPo (K, 271 hp), 390 GT (S, 320 hp), 427 (R/W, 425 hp). The K-code's last full year in the Fairlane.

VIN coding for 1967: 7 = year, plant, body, engine code in position five, sequence. Same code letters as 1966; the S-code 390 is now 320 hp.

1967 Ford Fairlane

Restoration notes specific to 1967: the 1967-only grille and trim are the identifiers against 1966s. The GT equipment checklist is the same discipline as 1966. The 289-block substitution means a late-1967 289 car can correctly carry a 302 casting — know the date codes before crying 'wrong block.'

Year-to-year changes at a glance.

■ Facelift: new grille, trim, interior. GT 390 now 320 hp.

■ 229 R-code 427 cars reported. GT convertible: 2,117.

■ Late-1967 302-casting 289 substitution. 238,658 built.

4. VIN Decoding

1967 Fairlane VINs: 7 = year, plant, body, engine code in position five, sequence.

Position

Meaning

Codes / Notes

Position 1

Model year

7 = 1967