

FREE SAMPLE

The opening pages of

1980 International Scout II Restoration Guide

Read these pages exactly as they appear in the full guide.
Nothing here is rewritten or summarised — it is the product itself,
so you can judge the depth before you spend a dollar.

full guide: <https://restoreessentials.com/product/RE-GD-INTERNATIONAL-SCOUT-II-1>

RestorationEssentials — instant PDF download after checkout.



RESTORATIONESSENTIALS

Factory-Correct Restoration Reference

1980 International Scout II Restoration Guide

Model Years 1980

Model	International Scout II + Terra/Traveler — final year
Platform	100-in Scout II; 118-in Terra/Traveler
Engines	196 I4; IH 304/345 V8; Nissan SD33T turbo diesel
Grille	One-piece ABS; SQUARE headlights
Notable	Dana 300; caster-corrected axle; production ends

Every specification in this guide was checked against factory literature, marque references, period road tests, and documented survivor vehicles. Where sources disagree or the record is silent, this guide says so rather than guessing.

Published by RestorationEssentials



How This Guide Works

This is a **single-year restoration** guide for the 1980 International Scout II — one year of the Fort Wayne-built Scout II (1971–1980), covered on its own because grilles, engines, ratings, and equipment changed every year, and a factory-correct restoration matches the year and the Line Setting Ticket, not the decade average. Specifications were checked against the range guide's base material, marque references (Crismon's International Trucks among them), and period histories. Where sources disagree, this guide prints the disagreement instead of guessing.

Scope. Covers 1980 Scout II in Traveltop, CabTop (half-cab), and soft-top form, 2WD and 4WD, plus the 118-inch Terra/Traveler where the year offers them. The Scout 80/800 predecessors have their own guides.

Where 1980 sits in the run

- Coming in: 1979 was the mechanical carryover and the SS-II's last year.
- Leaving: There is no 1981 Scout II — production ended in 1980 and IH left the light-truck business with it.

Year-Change Register — 1980

What makes a 1980 a 1980. Fit anything on this list from another year and the truck stops being factory-correct for its year.

- Final year of Scout production at Fort Wayne — and the most changed late year of the run.
- One-piece ABS grille with square headlights, in black or silver, with chrome headlight trim and the International name on the left — no other year looks like this.
- Dana 300 transfer case — regarded as nearly indestructible (range guide).
- Front-axle caster corrected; bodies get improved rust protection (range guide) — the best-driving Scout II of the run, and priced like it.
- Nissan SD33T TURBO diesel arrives — 1980 only (see the printed conflict in the 1979 guide).
- All 1980 Scouts are 4WD (marque summary). Specials: the '844' economy model (V8, 4-speed, 4WD) and the Shawnee off-road model.

Identity: VIN and the Line Setting Ticket

- The VIN is a 13-character string: series/engine prefix, body and series code, a model-year letter, the plant letter (G = Fort Wayne, Indiana), and the sequential serial. Record it from the plate and verify it against the frame stamping before anything else.
- The VIN tells you the series, not the equipment. The Line Setting Ticket — IH's build sheet listing engine, transmission, axle ratios, paint, and options as ordered — is the equipment authority.
- Tickets sometimes survive with the truck; if yours is gone, Light Line dealers (Super Scout Specialists, IH Parts America) can pull a reproduction ticket from the VIN. Order it before you buy parts.
- Cross-check every ticket line against the truck: engine code vs. casting, transmission vs. the tunnel, axle code vs. the differential tag, paint code vs. what is under the weatherstripping. Discrepancies are priced into the deal and written on the build sheet.



Engines — the 1980 Menu

Engine	Type	Notes
196 I4	IH four	Standard
304 V8	IH SV V8	Standard V8
345 V8	IH SV V8	Top gasoline option
SD33T	Nissan turbo diesel	New and 1980-only

The SD33T is the run's last engine story: the turbo version of the Nissan six, fitted for 1980 only. Verify a turbo truck by the ticket and the engine together — SD33Ts have been swapped into earlier trucks for decades, and a swap is a modification, however well done.

Chassis, Axles, and Brakes

The Dana 300 and the caster-corrected front axle make 1980 the chassis year: service the Dana 300 as its own unit (it is not the earlier transfer case with a new name), and preserve the corrected axle geometry at alignment — do not 'fix' a 1980 back to earlier caster figures.

- Frame and running gear are IH-industrial: leaf springs, solid axles, and (on 4WD) a two-speed transfer case with a single-speed unit standard in the early years — the ticket says which.
- Steering and brake work is system work: renew hydraulics, hoses, and wear items together, and verify axle ratios against the ticket and the differential tags.

Body, Rust, and the Tub Decision

- Scout bodies rust in predictable patterns: rockers, floor pans, body mounts, rear quarters, tailgate area, windshield frame, and the inner fenders. Budget for steel before budgeting for paint.
- Probe the body mounts and the tub structure first — a tub with sound mounts is restorable; a tub whose mounts have collapsed is a body-off decision.
- Replacement panels exist through the Light Line specialist network; complete tubs are the scarce item. A tub swap with the original VIN plate transferred is a title question, not a restoration detail.
- Check the frame stamping against the VIN plate before any bodywork; photograph the plate in place.

Tops, Interior, Paint, and Stripes

The removable-top system defines the Scout II: the steel Traveltop, the half-cab CabTop, or a soft top (plus, from 1976, the fiberglass Terra/Traveler tops). Seals and top hardware are restoration items, water-tested before the interior is finished. Paint and stripe/decal sets are year-specific — a stripe set from another year is a modification, not a restoration. Interior plaids and pads follow the ticket's trim line.

Restoration Sequence

1. Document: VIN plate (photographed in place), frame stamping, and the Line Setting Ticket — ordered from the VIN if it does not survive.
2. Rust triage before any purchase of trim or paint: mounts, floors, rockers, quarters, windshield frame.
3. The tub decision: repair in place, body-off, or (rare, documented) tub replacement — decided on the mounts and structure, not the cosmetics.